



## Function Call

Works fine



Causes the C0310 error -> C0310: Any parameter 'SourceA' of LogicAnd needs variable with write access as input



## Function Definition

```
1 {attribute 'hasanytype'}
2 FUNCTION LogicAND : BOOL
3 VAR_INPUT
4     EN: BOOL;
5     {attribute 'anytypeclass' := 'ANY'}
6     SourceA: ANY;
7     SourceB: ANY;
8     Dest : ANY;
9 END_VAR
10 VAR_IN_OUT
11 END_VAR
12 VAR_OUTPUT
13 END_VAR
```

## Move Function and multiple Data\_types

Move using constant to int, int to dint, and dint to dint

